





User Manual

airtouch.net.au


COOL



HEAT



FRESH /FAN



Modes and functions available depend on your Air Conditioning Unit.

Contents

Getting Started

Quick Start	2-3
Quick Menu & Controls	4-5
Adjusting Airflow for a Zone	6
Controlling Zone Temperature	7
Setting the AC Timer	8-9
Setting a Program	10-11
Assigning a Program	12-13
Turbo Zone	14-15
Setting up Favorites	16-17
Using ITC	18-19
AirTouch App & Integrations	20-21

Advanced System Settings

AirTouch Android OS Console	24
Naming Your Zones	25
Screen Lock	26
Owner's Name	27
Temperature Display	28
Balancing & Grouping Tables	29
WiFi & Internet Setup	30-31
Troubleshooting	32-33
Specifications	34-35


Quick Start - Console

Unit Selection
(Select to switch to other units if available)

Quick Menu Button

AC Unit On/Off Button

Current Temperature & Set Point



Zone Name & Airflow Percentage
Adjust with (+) and (-) buttons
To rename your Zones see page 25.
(Will display Set Point Temperature if you have optional Individual Temperature Control Sensors)

Mode
Cool, Fresh, Heat, Dry & Auto
(Depends on unit)

Slider
To change the temperature

System /AC Status

Fan Speed
AC ON/OFF
Quick Operations


Quick Start - Mobile App

Home Screen



Some Settings & Zone names setup on the AirTouch Console will be replicated in the App.

Zones Screen




Quick Menu & Controls


You can access common AirTouch features using the Quick Menu.

1

Access the **Quick Menu** by tapping on the menu icon ☰ in the top right.




Inside the Quick Menu



Turn On/Off AC


To turn On or Off AC either tap the **Power** button at the top



Or push and hold the button on the lower right corner

Adjusting Airflow for a Zone

Use the ⊕ and ⊖ buttons next to the zone names to increase or decrease the air flow in 5% increments.



Your zone names are on the left of the home screen.


By default, AirTouch lets you control the air volume in % for each zone.

Controlling Zone Temperature


If a zone has ITC installed, it can be controlled by temperature or airflow.

- 1 Use the \oplus and \ominus buttons to increase or decrease the set point in an individual zone.

*If a zone has ITC available, the air temperature/volume will have a rounded border.



- 2 To switch to °C temperature display (set point temperature for the zone), tap on the Air Volume %.



The air volume will automatically adjust according to the difference of set temperature and measured temperature in the zone.


Setting the AC Timer



The AC Timer function is useful for automatically switching the AC on or off at a given time.

The ON and OFF Timer function can be used in combination or separately for 1 or more AC units.

- 1 Open the **Quick Menu** and select **Programs** (see page 4).



2

Use the **Time** wheel to choose the time for each operation.

Program X

Program1 Program2 Program3 Program4 AC Timer Assignment

	Carrier	Toshiba	Samsung	UNIT4
ON	None	None	None	None
OFF	None	None	None	None


Cancel Please choose the time: None Confirm

hour minute

Setting a Program



A more advanced version of the Timer function is the **Program** function, letting you turn the AC ON or OFF and specify a Temperature for your entire house or individual zones.



1


Open the **Quick Menu** and select **Programs**.



2

Customise up to 4 **Programs** for any day of the week by tapping the Grid square for each ON and OFF Time, and the desired temperature.

- 3 Use the time wheel to choose each ON/OFF Time.



- 4 Use the keypad to enter the **Temperature** for each Programmed event.




- 4_b If you only want to use a Program in a certain zone/s, you will need to **Assign** it. See page 12.

Assigning a Program to a Zone or AC unit




A Program(s) must be set up before it can be Assigned. See page 10.



1

Open the **Quick Menu** and select **Programs**.




2

Select the **Assignment** option to see the list of the current programs available.

3

Tap on the **Program** menu of a zone or AC unit to show all program options. Tapping a program option will **Assign** the program to the zone or the AC unit.



4

To clear your choice, select **None**.

If a *Zone* has a **Program** event **Assigned**, the timer icon ⌚ will appear next to it.

If an *AC unit* has a **Program** event **Assigned** the timer icon ⌚ will appear next to its name at the top of the home screen.


Touch **Save** Button to Save.

Turbo Zone




For high volumes of conditioned air in a single zone.

AirTouch's Turbo Zone feature can cool or warm a single zone quickly; or can be useful when there is a lot of activity and you need more conditioned air than normal.



1

Open the **Quick Menu** and select **System settings**.





2


Tap on **Turbo Group** and a drop-down menu will appear. Select which room you want a larger volume of air.

- 3 To activate the **Turbo** function, tap on the  button again.

ON▶ Turbo▶ OFF



If there is more than one system, multiple Turbo groups can be set.




The Turbo function cannot be programmed.
It is activated manually from the console when needed.

Setting up Favourites




AirTouch's Favourites feature allows you to save your climate control scenarios.



1

Open the **Quick Menu** and select **Favourites**.




2

Create up to four **Favourite** presets. Select whether you want each zone ON or OFF.

3


Give your **Favourite(s)** option a name and you're good to go!

Tap **Save** button to save the setting.



Using ITC (Individual Temperature Control)

ITC Sensor & Button



Zone Button

- Press the button once to see if your Zone is ON or OFF

Blue Light = ON

Red Light = OFF

- Press the button again to change between ON or OFF

Replacing The battery

- 1 Remove the cover. Push the battery in the direction of the arrow on the pcb board. (as shown in the diagram on page 19)
- 2 When replacing the battery, press and hold the Zone Button (2) after removing the dead battery for 5 seconds to remove any residual charge from the circuit.

After replacing a battery you may need to pair the ITC sensor with AirTouch again.

The battery (3) used is 3V CR2450.

When the battery is low, a *Low Battery* icon (🔋) will appear near the zone name of the sensor.

A good battery will last for around 1 ½ to 2 years.

When the battery is flat, the zone will change to % control if there is no other sensor in it.


Pairing ITC Sensors with AirTouch

- 1 On the AirTouch console open the **Quick Menu** and select **System Settings > Installer > Sensors > Turn Sensor Pairing from Stop to Start**.

By default, the installer password is Polyaire.

- 2 After removing the cover from the ITC sensor, push and hold the Pairing Button (2) for 5 seconds until the LED (1) turns blue.

The zone name will appear on the sensor page of AirTouch 4 when the pairing is successful.



AirTouch 4 App

The AirTouch 4 App can be downloaded free of charge.



Install the AirTouch 4 App through the Apple App Store or Google Play Store.

After downloading the application, follow the prompts to link to your AirTouch console.

AirTouch 4 is compatible with:

- iOS 8.0 and above
- Android 4.0.3 and above




Integrations

We are constantly adding new Smart Home integrations to AirTouch to enhance the system's capabilities and your home living experience.

To learn more, and see how to set them up, visit airtouch.net.au.

IFTTT






NOTE:

If a mobile device is connected to the same WiFi network as your AirTouch 4, the app will automatically direct you to the control interface. Alternatively, if you are unable to access the control interface, you will be prompted for the AirTouch ID and password to continue. The AirTouch ID can be found in the Preferences section on the console.

When away from home the app will connect to AirTouch using your phones' 3G or 4G connection.



System Settings

AirTouch Console Android OS Functions

You can leave the AirTouch 4 Application and use the Android OS by swiping up from the bottom of the console to open the Android navigation bar and pressing the home button.

The following settings are configured through the Android OS:



Note:

Some of the Apps shown here are not preloaded

You can install any available Android Apps to your console to enhance the smart hub capability such as automated lighting or security systems as well as any lifestyle or entertainment Apps.


Disclaimer:

We cannot offer support for third party applications installed to, or modifications to the general settings of the Android OS installed on your AirTouch Console. While unlikely, installing third party applications, modifying the settings of or updating the Android OS of the AirTouch 4 Console may cause AirTouch to dysfunction.

Naming your Zones

*Zones are referred to as Groups in System Settings.

Customise AirTouch's Zone Names to suit your home



1

Open the **Quick Menu** and select **System settings**.

2

Select **Group Names** and edit individual **Groups** by tapping on the space provided to enter information.

To make it easy a preset name can be selected by selecting **Name List**.

Select **Save** to keep your changes.

Screen Lock




The Screen Lock Protects your Air Conditioning and AirTouch from potential damage caused by children playing with the console. It is set from within the Android OS.

1

Swipe up from the bottom of the console to open the Android navigation bar. Press on the Home button and Tap on Settings.




Go to Security and find the **Screen Lock**. It is set to None in default.



2

Select '**Screen Lock**' and follow the prompts to set it up.




Now, when the console goes to sleep and turns blank, you can unlock it using a password.


Owner's Name

Owner's Name is used by the mobile app to distinguish between AirTouch 4 systems.

The maximum length for a name is 16 letters.



- 1 Open the **Quick Menu** and select **System settings**.




- 2 Select **Preferences** and edit **Owner's Name** by tapping on the space provided to enter your details.

Select **Save** to keep your changes.

Temperature Display


*ITC Feature Only

If you have ITC, you can choose to see the actual temperature of each zone in the home screen.



1

Open the **Quick Menu** and select **System settings**.



2

Select **Preferences** and turn ON or OFF **Temperature Display** on the home screen.

Select **Save** to keep your changes.

Balance & Grouping Tables


(Filled in by your installer)

Group	Group Name	Zones Included	Sensors	Turbo Function	Balance
1					
2					
3					
4					
5					
6					
7					
8					
9					
A					
B					
C					
D					
E					
F					
G					

WiFi & Internet Setup




How to connect AirTouch 4 to a home router, which will enable the control/operation of AC unit and zoning via local WiFi and internet.




1

Open the **Quick Menu** and select **WiFi Settings**.




2

Select your desired WiFi network.




3 Enter WiFi network password then touch **Connect**.

4 Touch the **Triangle** on the navigation bar at the bottom of the screen to return to the AirTouch 4 app



Remote Internet Control




For remote AC control over the internet, ensure Internet Access is ticked under System Settings > Preferences.



Troubleshooting

Problem meets solution.

Problem	Suggested Action
LED in the lower right corner flashes quickly	No communication between the console and main module. Check if the AirTouch 4 App is running and the wiring.
LED flashes slowly (Every one second)	AC has an error. Either AC is faulty or the communications between AC and AirTouch 4 is lost. Call technician to further investigate.
No LED light	No power to the console.
Dampers have no response when turned on or off	<p>Check if LEDs on the main module light up for relevant zones when the zone dampers are being turned On/Off. If Green/Red LEDs are not activated for the respective zone, the main module may be faulty, replace it.</p> <p>If there is response, there might be a faulty cable and the cable would have to be replaced. If the zone is still non-functional then there might be a faulty damper motor.</p> <p>Check if the cable from touch-pad to the main control module is faulty. If it is a faulty cable, then replace the cable.</p> <p>Check Grouping and find out if the right zones have been assigned to the right groups and have been turned ON/OFF in Zoning section.</p>

Some zones cannot be turned off	<p>Check if 'Spill' status is displayed for the zone. Opening other zones will rectify the error</p> <p>*Check spill groups.</p>
No display on the LCD	<p>*Check if the cable is plugged in properly. Unplug the cable and reconnect it.</p> <p>*Check if there is power to the unit.</p>
LCD Display Corrupted	<p>Reset LCD by holding RESET button on the right side of the console for 2s.</p> <p>If error is still not resolved, reset console by unplugging the cable from behind and then reconnect it after about 15 seconds. If the corrupted display remains, power off/on the console. Otherwise, replace the console.</p>
WiFi symbol  disappeared from the touchpad	<p>After a power failure, AirTouch 4 will re-connect to home router and WiFi icon () will be back on in 3 minutes from Power ON.</p> <p>Turn the wireless router OFF and turn it back ON. Wait for 3 minutes for the AirTouch 4 system to initialise. If WiFi icon () does not appear, follow WiFi setup process to re-establish connection between your home router and AirTouch 4.</p>
The reaction of the AT4 app on the console is slow after the app has been running for a long time.	<p>Close the app and re-open the app.</p> <p>This needs to bring up the Android navigation bar at the bottom, press the left arrow button to close the app. Then restart the app.</p>
"AC ERRORxx" is on touchpad	<p>This error is displayed due to a fault with the AC unit. The AC ON/OFF function will be disabled when this error is displayed. The xx is the error code. Please call AC technician quoting the error code.</p>

Specifications

Electrical Requirements

Power supply: 24V AC $\pm 10\%$

Line frequency: 50 Hz

Environmental Requirements

Operating Temperature: 0°C to 60°C

Altitude: 0 to 2000 meters

Operating relative humidity: 10% to 80%

Avoid static electricity hazards

Avoid electromagnetic radiation sources

Avoid dust contamination

Avoid highly corrosive environments



Zone Output

Output voltage: 24VAC, 50Hz

Current: 200mA (1 damper motor)

Transformer

Input Voltage: 240VAC, 50Hz

Output Voltage: 24VAC, 50Hz

Wattage 40W

Supply Air Sensor NTC type, 10 k Ω at 25°C

Battery (Wireless Sensor) 3.0V, CR2450

Fuse Dimension 5x20 mm,
Fast-Acting 2A, 250V

1300 980 656



Liability and Disclaimer

All specifications and procedures are correct at time of publication, but are subject to change without notice. Please read the instructions before installing this Zone Control System. Polyaire Pty Ltd does not accept any responsibility for loss or damage that may occur as a result of the incorrect installation or operation of this AirTouch Control System.

Polyaire Pty Ltd

11-13 White Road

Gepps Cross South Australia, 5094

Tel: (08) 8349 8466 Fax: (08) 8349 8446

© Polyaire Pty Ltd 2018



Like us on Facebook
at facebook.com/meetAirTouch/



Subscribe to us on YouTube
at 'AirTouch'