

SETTING TIME



2. Press Shift button. Adjust is displayed "Mo" blinks

3. Press temp up/down to select day

1. Press Day Time button

SETTING TIME




5. Press temp up/down to set time

4. Press Shift button. Adjust is displayed "0000" blinks

6. Press Enter button. Set time & day displayed

SETTING TIMER (on/off)



1. Press ON/OFF timer button

2. Press Shift button. Adjust is displayed "01" blinks


4. Press Enter button normal display appears with "ON"

3. Press temp up/down to set timer ON hrs

Refer Pg15

To set "OFF TIMER" at step 1 press timer button twice to display "OFF". "ON & OFF" Timer can be combined.

SETTING SIMPLE 7 DAY TIMER



1. Press 7 Day Time Clock button.

To change to another day keep pressing the button.

2. Press Shift button.

Adjust is displayed "0000" blinks


3. Press temp up/down to set ON time

DAIKIN

SETTING SIMPLE 7 DAY TIMER

5. Press temp up/down to set OFF time

7. Press temp up/down to set mode




4. Press Shift button.
Adjust is displayed & OFF is showing

6. Press Shift button.
Adjust is displayed
"MODE" can be set

SETTING SIMPLE 7 DAY TIMER

9. Press temp up/down to set temperature



8. Press Shift button. Adjust is displayed & temperature can be set.


10. Press Enter button. PROG1 blinks

11. Press Test/Exit button to return to normal display.

To set program 2, press 7 Day Time clock Button again & repeat procedure

DAIKIN

SETTING SIMPLE 7 DAY TIMER (Using copy mode)




1. Press 7 Day Time Clock button to Select desired Program and Day of week to copy.

2. Press Shift button Adjust is displayed.

3. Press Enter button for 6 secs. Settings are copied to next day. Repeat if you need to copy to other days

DAIKIN


SETTING SIMPLE 7 DAY TIMER (Using copy mode)



4. Press Enter button PROG1 blinks

5. Press Test/Exit button to return to normal display.

SETTING MULTI 7 DAY TIMER



1. Press 7Day Time Clock button for 6 secs. To change to another day keep pressing button.


2. Press Shift button Adjust is displayed "0000" blinks

3. Press temp up/down to set ON time

Refer Pg16

SETTING MULTI 7 DAY TIMER

5. Press temp up/down to set OFF time




4. Press Shift button Adjust is displayed & OFF is showing

6. Press Shift button Adjust is displayed "MODE" can be set

7. Press temp up/down to set mode

SETTING MULTI 7 DAY TIMER

9. Press temp up/down to set temperature



8. Press Shift button Adjust is displayed & temperature can be set.


10. Press shift button and "Adjust Zone" is displayed

11. Select the desired zones by pressing any of the 8 zone buttons. LEDS of selected zones will light up.

DAIKIN

SETTING MULTI 7 DAY TIMER

15. Press Test/Exit button to return to normal display.




12. Press shift button and "Adjust Indoor" is displayed

14. Press Enter button PROG1 blinks. Press 7 Day Time Clock button to enter Program 2.

13. Press Sel Sensor button for sensor required

ZONE CONTROL

4. Zone1 LED lights up and Zone 1 is "ON".



2. Zone 1 is displayed on screen

1. Press Zone 1 button once.


3. Press Zone 1 button again.

CLEARING SETTINGS

To clear any of the settings you have made you need to go back into that setting and hold down the “CLEAR BUTTON” for at least 4 seconds.

Example; To cancel Simple 7 Day Timer.

CLEAR INDIVIDUAL SETTINGS



1. Press 7 Day Time Clock button. Keep pressing button until you reach required setting


2. Press shift button eg;0600 blinks.

3. Press clear button for 6 secs

4. Press Test/Exit button to return to normal display.



CLEAR ALL SIMPLE 7 DAY TIMER SETTINGS



1. Press 7 Day Time Clock button.

2. Press clear button for 6 secs

3. Press Test/Exit button to return to normal display.